

vipp

CARE INSTRUCTIONS

A close-up photograph of a silver metal lid, likely for a Vipp brand container. The lid is circular and has a brushed metal finish. The word "vipp" is engraved in a simple, lowercase, sans-serif font on the top surface. The lid is slightly raised from the base, and a small, flat, rectangular tab is visible on the left side. The background is a plain, light-colored surface, possibly white, which creates a soft shadow under the lid.

vipp

Congratulations on your new Vipp product

We have done our best to ensure that your Vipp product will bring you daily joy of use for many years to come. We hope that it meets your expectations.

If you wish to contact us, you can do so at www.vipp.com or on +45 4588 8800.

Warranty:

Towels and soap dispenser: 2 years warranty.

Other Vipp products: 10 years warranty. The extended warranty is valid for products purchased in 2008 or later. The warranty pre-supposes rightful use as described in Vipp's care instructions, with reservations for normal wear and tear. Please see Vipp's care instructions at www.vipp.com

To make the most out of your Vipp product, we recommend that you follow the maintenance instructions provided below:

Vipp 1-8 – Bathroom series

- Stainless steel surfaces should be cleaned and polished with a microfibre cloth, glass cleaner or other non-abrasive and gentle cleaning agents.
- Rubber parts should be cleaned with a moist cloth. Apply silicone spray for better finish.
- The rubber element of the shelf can be removed and re-attached with a single click and washed in the dishwasher.

Vipp 102-104 – Towels

- Wash at 60 °C before use. To achieve the best result, place the towels in icy water for one hour before first wash.
- Tumble-dry at the lowest temperature.
- Do not bleach or dryclean.



Vipp 9 – Soap dispenser

- If the soap does not flow through the pump at first, pump hot water through the pump head a few times.
- Before replacing the soap, we recommend cleaning the dispenser with hot water.
- The pump head can be cleaned by rinsing it with hot water.
- Stainless steel surfaces should be cleaned and polished with a microfibre cloth, glass cleaner or other non-abrasive and gentle cleaning agents.
- Lacquered surfaces should be cleaned with a moist cloth.
- Do not wash the dispenser in the dishwasher.
- Vipp products with dark surfaces should be cleaned with a soft brush and, if stained, with a bit of water. Then wipe with dry cloth.

Vipp 11 – Toilet brush

- Stainless steel surfaces should be cleaned and polished with a microfibre cloth, glass cleaner or other non-abrasive and gentle cleaning agents.
- Lacquered surfaces should be cleaned with a moist cloth.
- The inner tube can be removed for cleaning.
- The brush head can be replaced and purchased separately. Find your nearest dealer at www.vipp.com.
- Vipp products with dark surfaces should be cleaned with a soft brush and, if stained, with a bit of water. Then wipe with dry cloth.

Vipp 13-52 – Pedal bins and office bins

- Stainless steel surfaces should be cleaned and polished with a microfibre cloth, glass cleaner or other non-abrasive and gentle cleaning agents.
- Lacquered surfaces should be cleaned with a moist cloth.
- Rubber parts should be cleaned with a moist cloth. Apply silicone spray for better finish.
- Special Vipp bin liners can be purchased separately. Find your nearest dealer at www.vipp.com.
- Vipp products with dark surfaces should be cleaned with a soft brush and, if stained, with a bit of water. Then wipe with dry cloth.

Vipp 441 – Laundry basket

- Stainless steel surfaces should be cleaned and polished with a microfibre cloth, glass cleaner or other non-abrasive and gentle cleaning agents.
- Lacquered surfaces should be cleaned with a moist cloth.
- Inner bag can be machine washed at max. 40 °C - do not tumble-dry.
- Vipp products with dark surfaces should be cleaned with a soft brush and, if stained, with a bit of water. Then wipe with dry cloth.





